


Installation Instructions

Single cell units in steel casing penetrating masonry wall

1. Position damper centrally in penetration aperture as per System Drawing.
2. Fire-stop any gaps between the damper & building element with Kilargo Intumescent Mastic (supplied separately). Ensure fill depth corresponds with those detailed in the System Drawing.
3. Fasten mounting angles to both sides of damper casing with steel self drilling screws or steel pop rivets.
4. If connecting ductwork to the installed damper casing ensure that an appropriate AS1682.2 compliant breakaway joint method is used.
5. Ensure product and certification labels are in a prominent position for easy identification during subsequent maintenance inspections.
6. Ensure convenient access is provided for visual inspection and cleaning as necessary.

Notes

1. Product must be fitted in accordance with this detail, including the use of Kilargo Intumescent Mastic to ensure compliance with Kilargo Fire Test Approval detailed.
2. Retaining angles & fixing screws are to be supplied by others.



| | |
|--------------------|--|
| Building Element | Masonry |
| Application | Mounted in steel casing in penetration |
| Maximum Size | 250mm x 250mm |
| FRL | -/ 240 /- |
| Test Reference No. | WFRA C91525 |

System No. **WM2**